

## UNIVERSAL UTILITY VEHICLE ROOF W/CARGO AREA

### **PLEASE NOTE:**

- 1. IT IS RECOMMENDED TO REMOVE THIS ROOF BEFORE TRANSPORTING ON ANY OPEN TRAILER OR VEHICLE**
- 2. THE MAXIMUM LOAD CAPACITY OF THE CARGO AREA IS 40 LBS.**
- 3. IT IS RECOMMENDED THAT THIS ROOF BE ASSEMBLED AT AN AMBIENT TEMPERATURE OVER 60 DEGREES**

### **TOOLS REQUIRED FOR INSTALLATION:**

ITEM	DESCRIPTION
1	DRILL
2	1/4" DRILL BIT
3	TAPE MEASURE
4	MARKING UTENSIL
5	TWO 7/16" WRENCHES OR SOCKET WRENCHES

### **PARTS LIST:**

1	4 1 7/8" CLAMP
2	4 2" CLAMP
3	4 1" X 1/4"-28 SS BOLT
4	4 1" FENDER WASHER
5	4 1/4"-28 NYLON INSERT NUTS

**NOTE: YOU WILL ONLY USE ONE SIZE CLAMP FOR THIS INSTALLATION. TWO SIZES ARE PROVIDED TO ACCOMMODATE MULTIPLE VEHICLES.**

### **INSTALLATION:**

- PLACE THE UNIVERSAL ROOF ON TOP OF THE ROLL CAGE IN THE DESIRED LOCATION FRONT TO BACK CENTERING THE ROOF SIDE TO SIDE
- FIND THE BEST LOCATION ON YOUR VEHICLE FOR THE CLAMPS THAT WOULD ALLOW A ONE INCH WASHER TO BE PLACED FLAT WHEN TIGHTENED INTO PLACE:

**NOTE: PLACING THE CLAMPS AS FAR TO THE OUTSIDE OF THE VEHICLE AS POSSIBLE WILL PROVIDE THE BEST END RESULTS.**

- CHECK THE SIZE OF THE BARS AT THESE LOCATIONS AND PLACE THE PROPER SIZE CLAMP ON THE BARS. (TWO SIZES PROVIDED)
- MARK THE LOCATION OF THE MOUNTING HOLES FOR THE CLAMPS AND DRILL 4 HOLES WITH A 1/4" DRILL BIT.
- PLACE A FENDER WASHER ON THE 1/4" BOLT AND FEED IT THROUGH THE ROOF FROM THE TOP DOWN FOR ALL FOUR HOLES
- PLACE THE CLAMPS OVER THE BOLTS THEN A FENDER WASHER AND SECURE WITH THE 1/4" NYLON INSERT NUT.

## UNIVERSAL UTILITY VEHICLE ROOF W/CARGO AREA

### **PLEASE NOTE:**

- 1. IT IS RECOMMENDED TO REMOVE THIS ROOF BEFORE TRANSPORTING ON ANY OPEN TRAILER OR VEHICLE**
- 2. THE MAXIMUM LOAD CAPACITY OF THE CARGO AREA IS 40 LBS.**
- 3. IT IS RECOMMENDED THAT THIS ROOF BE ASSEMBLED AT AN AMBIENT TEMPERATURE OVER 60 DEGREES**

### **TOOLS REQUIRED FOR INSTALLATION:**

ITEM	DESCRIPTION
1	DRILL
2	1/4" DRILL BIT
3	TAPE MEASURE
4	MARKING UTENSIL
5	TWO 7/16" WRENCHES OR SOCKET WRENCHES

### **PARTS LIST:**

1	4 1 7/8" CLAMP
2	4 2" CLAMP
3	4 1" X 1/4"-28 SS BOLT
4	4 1" FENDER WASHER
5	4 1/4"-28 NYLON INSERT NUTS

**NOTE: YOU WILL ONLY USE ONE SIZE CLAMP FOR THIS INSTALLATION. TWO SIZES ARE PROVIDED TO ACCOMMODATE MULTIPLE VEHICLES.**

### **INSTALLATION:**

- PLACE THE UNIVERSAL ROOF ON TOP OF THE ROLL CAGE IN THE DESIRED LOCATION FRONT TO BACK CENTERING THE ROOF SIDE TO SIDE
- FIND THE BEST LOCATION ON YOUR VEHICLE FOR THE CLAMPS THAT WOULD ALLOW A ONE INCH WASHER TO BE PLACED FLAT WHEN TIGHTENED INTO PLACE:

**NOTE: PLACING THE CLAMPS AS FAR TO THE OUTSIDE OF THE VEHICLE AS POSSIBLE WILL PROVIDE THE BEST END RESULTS.**

- CHECK THE SIZE OF THE BARS AT THESE LOCATIONS AND PLACE THE PROPER SIZE CLAMP ON THE BARS. (TWO SIZES PROVIDED)
- MARK THE LOCATION OF THE MOUNTING HOLES FOR THE CLAMPS AND DRILL 4 HOLES WITH A 1/4" DRILL BIT.
- PLACE A FENDER WASHER ON THE 1/4" BOLT AND FEED IT THROUGH THE ROOF FROM THE TOP DOWN FOR ALL FOUR HOLES
- PLACE THE CLAMPS OVER THE BOLTS THEN A FENDER WASHER AND SECURE WITH THE 1/4" NYLON INSERT NUT.