

UNIVERSAL FRONT ROTO BASKET

PLEASE NOTE: MAXIMUM CAPACITY OF THIS BASKET SHOULD NOT EXCEED THE RECOMMENDED FRONT RACK CAPACITY OF YOUR SPECIFIC MODEL.

PARTS LIST:

ITEM	QTY	DESCRIPTION
1	1	UNIVERSAL FRONT BASKET
2	4	1/4" U-BOLTS
3	8	1/4" NYLOCK WING NUT
4	4	MOUNTING PLATES FOR U-BOLTS

TOOLS REQUIRED:

DRILL
1/4" DRILL BIT
TAPE MEASURE

INSTALLATION:

- A) PLACE THE UNIVERSAL FRONT BASKET ON THE TOP OF THE FRONT RACK. (MAKE SURE THE BOX IS CENTERED PROPERLY ON YOUR ATV.)
- B) FIND THE BEST LOCATION TO PLACE YOUR U-BOLTS. (U-BOLTS NEED TO GO AROUND A RACK SUPPORT BAR. PLACE THE U-BOLTS AS CLOSE TO THE CORNERS OF YOUR RACK. THIS WILL PROVIDE BETTER SUPPORT.)
- C) DRILL THE HOLES FOR THE FOUR U-BOLTS.
- D) PLACE THE BASKET ON THE FRONT RACK OF YOUR ATV AND INSERT THE U-BOLTS FROM THE INSIDE. PLACE THE MOUNTING PLATES ON THE U-BOLTS AND INSTALL THE WING NUTS. SECURE THE WING NUTS TIGHTLY.

NOTE: MAKE SURE YOUR BASKET IS MOUNTED TIGHT SO IT WILL NOT RATTLE OR SLIDE AROUND.

UNIVERSAL FRONT ROTO BASKET

PLEASE NOTE: MAXIMUM CAPACITY OF THIS BASKET SHOULD NOT EXCEED THE RECOMMENDED FRONT RACK CAPACITY OF YOUR SPECIFIC MODEL.

PARTS LIST:

ITEM	QTY	DESCRIPTION
1	1	UNIVERSAL FRONT BASKET
2	4	1/4" U-BOLTS
3	8	1/4" NYLOCK WING NUT
4	4	MOUNTING PLATES FOR U-BOLTS

TOOLS REQUIRED:

DRILL
1/4" DRILL BIT
TAPE MEASURE

INSTALLATION:

- A) PLACE THE UNIVERSAL FRONT BASKET ON THE TOP OF THE FRONT RACK. (MAKE SURE THE BOX IS CENTERED PROPERLY ON YOUR ATV.)
- B) FIND THE BEST LOCATION TO PLACE YOUR U-BOLTS. (U-BOLTS NEED TO GO AROUND A RACK SUPPORT BAR. PLACE THE U-BOLTS AS CLOSE TO THE CORNERS OF YOUR RACK. THIS WILL PROVIDE BETTER SUPPORT.)
- C) DRILL THE HOLES FOR THE FOUR U-BOLTS.
- D) PLACE THE BASKET ON THE FRONT RACK OF YOUR ATV AND INSERT THE U-BOLTS FROM THE INSIDE. PLACE THE MOUNTING PLATES ON THE U-BOLTS AND INSTALL THE WING NUTS. SECURE THE WING NUTS TIGHTLY.

NOTE: MAKE SURE YOUR BASKET IS MOUNTED TIGHT SO IT WILL NOT RATTLE OR SLIDE AROUND.