

## UNIVERSAL FRONT CARGO BOX

PLEASE NOTE: MAXIMUM CAPACITY OF THIS CARGO BOX SHOULD NOT EXCEED THE RECOMMENDED FRONT RACK CAPACITY OF YOUR SPECIFIC MODEL.

### PARTS LIST:

ITEM	QTY	DESCRIPTION
1	1	UNIVERSAL FRONT CARGO BOX
2	4	2" X 1/4" U-BOLTS*
3	4	2 5/8" X 1/4" U-BOLTS*
4	8	1/4" WING NUT
5	4	MOUNTING PLATES FOR U-BOLTS

\* For your convenience this kit is designed for you to use which ever length U-bolt is appropriate for your application.

### TOOLS REQUIRED:

DRILL  
1/4" DRILL BIT  
TAPE MEASURE

### INSTALLATION:

- A) PLACE THE UNIVERSAL FRONT CARGO BOX ON THE TOP OF THE FRONT RACK. (MAKE SURE THE BOX IS CENTERED PROPERLY ON YOUR ATV.)
- B) FIND THE BEST LOCATION TO PLACE YOUR U-BOLTS. (U-BOLTS NEED TO GO AROUND A RACK SUPPORT BAR. PLACE THE U-BOLTS AS CLOSE TO THE CORNERS OF YOUR RACK. THIS WILL PROVIDE BETTER SUPPORT.)
- C) DRILL THE HOLES FOR THE FOUR U-BOLTS.
- D) PLACE THE CARGO BOX ON THE FRONT RACK OF YOUR ATV AND INSERT THE U-BOLTS FROM THE INSIDE. PLACE THE MOUNTING PLATES ON THE U-BOLTS AND INSTALL THE WING NUTS. SECURE THE WING NUTS TIGHTLY.

NOTE: MAKE SURE YOUR CARGO BOX IS MOUNTED TIGHT SO IT WILL NOT RATTLE OR SLIDE AROUND.

## UNIVERSAL FRONT CARGO BOX

PLEASE NOTE: MAXIMUM CAPACITY OF THIS CARGO BOX SHOULD NOT EXCEED THE RECOMMENDED FRONT RACK CAPACITY OF YOUR SPECIFIC MODEL.

### PARTS LIST:

ITEM	QTY	DESCRIPTION
1	1	UNIVERSAL FRONT CARGO BOX
2	4	2" X 1/4" U-BOLTS*
3	4	2 5/8" X 1/4" U-BOLTS*
4	8	1/4" WING NUT
5	4	MOUNTING PLATES FOR U-BOLTS

\* For your convenience this kit is designed for you to use which ever length U-bolt is appropriate for your application.

### TOOLS REQUIRED:

DRILL  
1/4" DRILL BIT  
TAPE MEASURE

### INSTALLATION:

- A) PLACE THE UNIVERSAL FRONT CARGO BOX ON THE TOP OF THE FRONT RACK. (MAKE SURE THE BOX IS CENTERED PROPERLY ON YOUR ATV.)
- B) FIND THE BEST LOCATION TO PLACE YOUR U-BOLTS. (U-BOLTS NEED TO GO AROUND A RACK SUPPORT BAR. PLACE THE U-BOLTS AS CLOSE TO THE CORNERS OF YOUR RACK. THIS WILL PROVIDE BETTER SUPPORT.)
- C) DRILL THE HOLES FOR THE FOUR U-BOLTS.
- D) PLACE THE CARGO BOX ON THE FRONT RACK OF YOUR ATV AND INSERT THE U-BOLTS FROM THE INSIDE. PLACE THE MOUNTING PLATES ON THE U-BOLTS AND INSTALL THE WING NUTS. SECURE THE WING NUTS TIGHTLY.

NOTE: MAKE SURE YOUR CARGO BOX IS MOUNTED TIGHT SO IT WILL NOT RATTLE OR SLIDE AROUND.